

# ECODESIGN INFORMATION

Applies to non-residential ventilation units (NRVU)

According to Regulation EU No 1253/2014 of the European Commission, implementing Directive 2009/125/CE of European Parliament

SODECA, S.L.U.

www.sodeca.com

c) Typology  
d) Type of drive  
e) Type of HRS

g) Nominal flowrate  
h) Effective electric power input  
i) SFPint

k) Nominal external pressure  
l) Internal pressure drop of ventilation components  
m) Internal pressure drop of non-ventilation components

327/2011  
o1) Max. Internal leakage index  
o2) Max. External leakage index  
p) Energy performance of the filters

r) LWA radiated

b)	c)	d)	e)	f)	g)	h)	i)	j)	k)	l)	m)	n)	o1)	o2)	p)	q)	r)	ERP
				%	m <sup>3</sup> /s	kW	W/m <sup>3</sup> /s	m/s	Pa	Pa	Pa	%	%	%			dBA	
UFR-1240-4T G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	0.688	0.553	230	1.68	193	78	51.4	0.4	G4: G; F6: F	Siehe Anleitung	76	2018			
UFR-1850-4T G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	0.693	1.295	230	1.69	561	79	57.3	0.4	G4: G; F6: F	Siehe Anleitung	86	2018			
UFR-2056-4T G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	1.726	2.083	230	2.96	359	85	57.8	0.2	G4: G; F6: F	Siehe Anleitung	88	2018			
UFR-2056-6T G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	1.493	0.655	230	2.56	57	63	52.8	0.3	G4: G; F6: F	Siehe Anleitung	78	2018			
UFR-2263-4T G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	1.144	3.629	230	1.63	770	60	60.9	0.4	G4: G; F6: F	Siehe Anleitung	92	2018			
UFR-2263-6T G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	1.469	1.360	230	2.52	276	91	59.0	0.3	G4: G; F6: F	Siehe Anleitung	82	2018			
UFR-2071-4T G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	1.045	4.877	230	1.29	1018	53	64.0	0.5	G4: G; F6: F	Siehe Anleitung	101	2018			
UFR-2071-6T-3 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	1.202	2.387	230	1.71	507	66	59.4	0.4	G4: G; F6: F	Siehe Anleitung	86	2018			
UFR-2071-6T-5.5 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	1.056	2.121	230	1.30	417	54	59.2	0.5	G4: G; F6: F	Siehe Anleitung	88	2018			
UFR-2880-6T G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	1.181	2.937	230	1.46	662	67	59.7	0.4	G4: G; F6: F	Siehe Anleitung	89	2018			
UFR-1240-4T F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	0.763	0.569	230	1.86	168	75	51.4	0.4	F6: F; F8: A	Siehe Anleitung	76	2018			
UFR-1850-4T F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	0.807	1.347	230	1.97	523	84	57.3	0.4	F6: F; F8: A	Siehe Anleitung	86	2018			
UFR-2056-4T F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	1.962	2.084	230	3.37	267	74	57.8	0.2	F6: F; F8: A	Siehe Anleitung	88	2018			
UFR-2056-6T F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	1.595	0.638	230	2.74	36	49	52.8	0.2	F6: F; F8: A	Siehe Anleitung	78	2018			
UFR-2263-4T F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	1.318	3.860	230	1.88	750	64	60.9	0.3	F6: F; F8: A	Siehe Anleitung	92	2018			
UFR-2263-6T F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	1.636	1.361	230	2.81	232	88	59.0	0.2	F6: F; F8: A	Siehe Anleitung	82	2018			
UFR-2071-4T F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	1.206	5.174	230	1.49	1006	57	64.0	0.4	F6: F; F8: A	Siehe Anleitung	101	2018			
UFR-2071-6T-3 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	1.402	2.447	230	2.00	477	72	59.4	0.3	F6: F; F8: A	Siehe Anleitung	86	2018			
UFR-2071-6T-5.5 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	1.212	2.243	230	1.50	405	58	59.2	0.4	F6: F; F8: A	Siehe Anleitung	88	2018			
UFR-2880-6T F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	1.366	3.068	230	1.69	641	73	59.7	0.4	F6: F; F8: A	Siehe Anleitung	89	2018			
UFR-1240-4T F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	0.724	0.561	230	1.77	181	76	51.4	0.4	F7: A; F9: A	Siehe Anleitung	76	2018			
UFR-1850-4T F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	0.746	1.320	230	1.82	544	81	57.3	0.4	F7: A; F9: A	Siehe Anleitung	86	2018			
UFR-2056-4T F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	1.839	2.088	230	3.16	316	80	57.8	0.2	F7: A; F9: A	Siehe Anleitung	88	2018			
UFR-2056-6T F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	1.544	0.647	230	2.65	46	57	52.8	0.3	F7: A; F9: A	Siehe Anleitung	78	2018			
UFR-2263-4T F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	1.225	3.737	230	1.74	761	62	60.9	0.4	F7: A; F9: A	Siehe Anleitung	92	2018			
UFR-2263-6T F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	1.550	1.363	230	2.66	255	90	59.0	0.3	F7: A; F9: A	Siehe Anleitung	82	2018			
UFR-2071-4T F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	1.120	5.015	230	1.38	1012	55	64.0	0.4	F7: A; F9: A	Siehe Anleitung	101	2018			
UFR-2071-6T-3 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	1.295	2.417	230	1.84	493	69	59.4	0.3	F7: A; F9: A	Siehe Anleitung	86	2018			
UFR-2071-6T-5.5 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	1.129	2.178	230	1.39	411	56	59.2	0.4	F7: A; F9: A	Siehe Anleitung	88	2018			
UFR-2880-6T F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	1.268	3.000	230	1.57	652	70	59.7	0.4	F7: A; F9: A	Siehe Anleitung	89	2018			