

ECODESIGN INFORMATION

Applies to non-residential ventilation units (NRVU)

According to Regulation EU No 1253/2014 of the European Commission, implementing Directive 2009/125/CE of European Parliament

SODECA, S.L.U.

www.sodeca.com

c) Typology
d) Type of drive
e) Type of HRS

g) Nominal flowrate
h) Effective electric power input
i) SFPint

k) Nominal external pressure
l) Internal pressure drop of ventilation components
m) Internal pressure drop of non-ventilation components

327/2011
o1) Max. Internal leakage index
o2) Max. External leakage index
p) Energy performance of the filters

r) LWA radiated

b)	c)	d)	e)	f)	g)	h)	i)	j)	k)	l)	m)	n)	o1)	o2)	p)	q)	r)	ERP
				%	m ³ /s	KW	W/m ³ /s	m/s	Pa	Pa	Pa	%	%	%			dBA	
UFRX-315-0.5 G4+F6	NRVU / UVU	Variable Drehzahl	Kein/e		1.374	0.754	230	2.10	77	56		47.9	0.3		G4: G; F6: F	Siehe Anleitung	74	2018
UFRX-315-0.75 G4+F6	NRVU / UVU	Variable Drehzahl	Kein/e		1.454	0.976	230	2.22	120	63		53.2	0.3		G4: G; F6: F	Siehe Anleitung	72	2018
UFRX-315-1 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		1.597	0.982	230	2.44	126	75		59.3	0.2		G4: G; F6: F	Siehe Anleitung	74	2018
UFRX-315-1.5 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		1.678	1.208	230	2.56	177	83		61.2	0.2		G4: G; F6: F	Siehe Anleitung	77	2018
UFRX-315-2 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		1.743	1.497	230	2.66	246	90		62.5	0.2		G4: G; F6: F	Siehe Anleitung	79	2018
UFRX-315-3 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		1.812	1.783	230	2.76	318	97		63.1	0.2		G4: G; F6: F	Siehe Anleitung	82	2018
UFRX-355-0.75 G4+F6	NRVU / UVU	Variable Drehzahl	Kein/e		1.814	0.812	230	1.48	38	41		50.8	0.4		G4: G; F6: F	Siehe Anleitung	71	2018
UFRX-355-1 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		1.961	0.789	230	1.59	36	47		59.0	0.3		G4: G; F6: F	Siehe Anleitung	73	2018
UFRX-355-1.5 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		2.169	1.141	230	1.76	75	58		60.8	0.3		G4: G; F6: F	Siehe Anleitung	76	2018
UFRX-355-2 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		2.361	1.580	230	1.92	131	69		62.2	0.3		G4: G; F6: F	Siehe Anleitung	78	2018
UFRX-355-3 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		2.527	2.165	230	2.05	215	79		62.8	0.3		G4: G; F6: F	Siehe Anleitung	80	2018
UFRX-355-4 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		2.739	3.284	230	2.23	390	93		63.3	0.2		G4: G; F6: F	Siehe Anleitung	83	2018
UFRX-355-5.5 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		2.935	4.555	230	2.39	611	106		65.0	0.2		G4: G; F6: F	Siehe Anleitung	85	2018
UFRX-400-1.5 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		2.353	0.661	230	1.91	4	19		60.4	0.3		G4: G; F6: F	Siehe Anleitung	78	2018
UFRX-400-2 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		2.538	0.825	230	2.06	9	23		61.7	0.3		G4: G; F6: F	Siehe Anleitung	80	2018
UFRX-400-3 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		2.896	1.284	230	2.36	27	29		62.5	0.2		G4: G; F6: F	Siehe Anleitung	83	2018
UFRX-400-4 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		3.945	3.956	230	3.21	184	55		63.0	0.2		G4: G; F6: F	Siehe Anleitung	85	2018
UFRX-400-5.5 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		4.245	5.048	230	3.45	264	63		64.7	0.2		G4: G; F6: F	Siehe Anleitung	88	2018
UFRX-400-7.5 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		4.510	6.531	230	3.67	379	72		67.0	0.1		G4: G; F6: F	Siehe Anleitung	90	2018
UFRX-450-2 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		2.726	0.719	230	1.38	6	42		61.3	0.3		G4: G; F6: F	Siehe Anleitung	82	2018
UFRX-450-3 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		3.173	1.282	230	1.61	43	56		62.0	0.3		G4: G; F6: F	Siehe Anleitung	85	2018
UFRX-450-4 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		4.057	3.838	230	2.06	287	92		62.6	0.2		G4: G; F6: F	Siehe Anleitung	87	2018
UFRX-450-5.5 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		4.320	5.371	230	2.19	460	104		64.3	0.2		G4: G; F6: F	Siehe Anleitung	90	2018
UFRX-450-7.5 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		4.550	7.138	230	2.31	675	116		66.6	0.2		G4: G; F6: F	Siehe Anleitung	92	2018
UFRX-450-10 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		4.710	9.379	230	2.39	951	124		65.2	0.2		G4: G; F6: F	Siehe Anleitung	94	2018
UFRX-500-2 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		5.072	3.253	230	2.57	97	54		63.3	0.2		G4: G; F6: F	Siehe Anleitung	83	2018
UFRX-500-3 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		5.387	4.069	230	2.73	139	61		64.0	0.2		G4: G; F6: F	Siehe Anleitung	86	2018
UFRX-500-4 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		5.237	3.604	230	2.66	115	58		64.7	0.2		G4: G; F6: F	Siehe Anleitung	88	2018
UFRX-500-5.5 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		5.552	4.421	230	2.82	159	65		66.3	0.2		G4: G; F6: F	Siehe Anleitung	90	2018
UFRX-500-7.5 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		6.141	6.386	230	3.12	279	79		68.6	0.2		G4: G; F6: F	Siehe Anleitung	92	2018
UFRX-500-10 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		6.660	8.922	230	3.38	450	93		69.7	0.1		G4: G; F6: F	Siehe Anleitung	95	2018
UFRX-500-15 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		7.114	12.027	230	3.61	675	106		69.7	0.1		G4: G; F6: F	Siehe Anleitung	98	2018
UFRX-500-20 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		7.288	14.030	230	3.70	822	112		69.2	0.1		G4: G; F6: F	Siehe Anleitung	99	2018
UFRX-560-3 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		4.817	2.108	230	1.65	51	57		63.6	0.2		G4: G; F6: F	Siehe Anleitung	72	2018
UFRX-560-4 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		5.232	2.878	230	1.79	93	67		64.3	0.2		G4: G; F6: F	Siehe Anleitung	75	2018
UFRX-560-5.5 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		5.948	4.954	230	2.04	226	86		66.0	0.2		G4: G; F6: F	Siehe Anleitung	77	2018
UFRX-560-7.5 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		6.535	7.668	230	2.24	427	104		68.4	0.2		G4: G; F6: F	Siehe Anleitung	79	2018
UFRX-560-10 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		6.780	9.278	230	2.32	554	112		69.2	0.2		G4: G; F6: F	Siehe Anleitung	81	2018
UFRX-560-15 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		7.160	13.111	230	2.45	869	125		69.2	0.2		G4: G; F6: F	Siehe Anleitung	84	2018
UFRX-560-20 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		7.376	17.954	230	2.53	1270	133		69.1	0.2		G4: G; F6: F	Siehe Anleitung	87	2018
UFRX-560-25 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		7.524	20.226	230	2.58	1474	138		69.7	0.2		G4: G; F6: F	Siehe Anleitung	89	2018
UFRX-560-30 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		7.492	20.406	230	2.57	1482	137		69.7	0.2		G4: G; F6: F	Siehe Anleitung	89	2018
UFRX-630-3 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		6.622	2.602	230	2.27	32	45		60.7	0.2		G4: G; F6: F	Siehe Anleitung	74	2018
UFRX-630-4 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		7.924	5.136	230	2.71	118	65		61.3	0.2		G4: G; F6: F	Siehe Anleitung	77	2018
UFRX-630-5.5 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		8.503	6.814	230	2.91	185	75		62.8	0.1		G4: G; F6: F	Siehe Anleitung	79	2018
UFRX-630-7.5 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		9.048	8.700	230	3.10	269	85		65.0	0.1		G4: G; F6: F	Siehe Anleitung	81	2018
UFRX-630-10 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		9.528	10.978	230	3.26	376	94		66.1	0.1		G4: G; F6: F	Siehe Anleitung	84	2018
UFRX-630-15 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		10.316	16.660	230	3.53	661	110		66.1	0.1		G4: G; F6: F	Siehe Anleitung	86	2018
UFRX-630-20 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		10.589	20.321	230	3.63	850	116		66.0	0.1		G4: G; F6: F	Siehe Anleitung	89	2018
UFRX-630-25 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		10.655	19.911	230	3.65	835	117		67.1	0.1		G4: G; F6: F	Siehe Anleitung	90	2018
UFRX-630-30 G4+F6 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		10.622	20.114	230	3.64	842	116		66.6	0.1		G4: G; F6: F	Siehe Anleitung	92	2018
UFRX-315-0.5 F6+F8	NRVU / UVU	Variable Drehzahl	Kein/e		1.451	0.730	230	2.21	51	43		47.9	0.3		F6: F; F8: A	Siehe Anleitung	74	2018
UFRX-315-0.75 F6+F8	NRVU / UVU	Variable Drehzahl	Kein/e		1.550	0.947	230	2.36	81	49		53.2	0.3		F6: F; F8: A	Siehe Anleitung	72	2018
UFRX-315-1 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		1.695	0.951	230	2.58	84	59		59.3	0.2		F6: F; F8: A	Siehe Anleitung	74	2018
UFRX-315-1.5 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		1.794	1.173	230	2.74	121	66		61.2	0.2		F6: F; F8: A	Siehe Anleitung	77	2018
UFRX-315-2 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		1.880	1.460	230	2.87	171	72		62.5	0.2		F6: F; F8: A	Siehe Anleitung	79	2018
UFRX-315-3 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		1.967	1.746	230	3.00	226	79		63.1	0.2		F6: F; F8: A	Siehe Anleitung	82	2018
UFRX-355-0.75 F6+F8	NRVU / UVU	Variable Drehzahl	Kein/e		1.849	0.801	230	1.50	30	35		50.8	0.3		F6: F; F8: A	Siehe Anleitung	71	2018
UFRX-355-1 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		1.996	0.778	230	1.62	28	40		59.0	0.3		F6: F; F8: A	Siehe Anleitung	73	2018

ECODESIGN INFORMATION

Applies to non-residential ventilation units (NRVU)

According to Regulation EU No 1253/2014 of the European Commission, implementing Directive 2009/125/CE of European Parliament

SODECA, S.L.U.

www.sodeca.com

				%	m³/s	kW	W/m³/s	m/s	Pa	Pa	Pa	%	%	%			dBA	
UFRX-355-1.5 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		2.217	1.124	230	1.80	60	50		60.8		0.3	F6: F; F8: A	Siehe Anleitung	76	2018
UFRX-355-2 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		2.424	1.556	230	1.97	106	59		62.2		0.3	F6: F; F8: A	Siehe Anleitung	78	2018
UFRX-355-3 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		2.609	2.134	230	2.12	176	69		62.8		0.2	F6: F; F8: A	Siehe Anleitung	80	2018
UFRX-355-4 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		2.852	3.246	230	2.32	325	82		63.3		0.2	F6: F; F8: A	Siehe Anleitung	83	2018
UFRX-355-5.5 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		3.079	4.521	230	2.50	516	96		65.0		0.2	F6: F; F8: A	Siehe Anleitung	85	2018
UFRX-400-1.5 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		2.397	0.646	230	1.95	1	7		60.4		0.3	F6: F; F8: A	Siehe Anleitung	78	2018
UFRX-400-2 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		2.593	0.804	230	2.11	3	9		61.7		0.2	F6: F; F8: A	Siehe Anleitung	80	2018
UFRX-400-3 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		2.980	1.241	230	2.42	9	11		62.5		0.2	F6: F; F8: A	Siehe Anleitung	83	2018
UFRX-400-4 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		4.197	3.734	230	3.41	65	23		63.0		0.2	F6: F; F8: A	Siehe Anleitung	85	2018
UFRX-400-5.5 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		4.563	4.742	230	3.71	95	27		64.7		0.1	F6: F; F8: A	Siehe Anleitung	88	2018
UFRX-400-7.5 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		4.916	6.107	230	4.00	137	31		67.0		0.1	F6: F; F8: A	Siehe Anleitung	90	2018
UFRX-450-2 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		2.760	0.709	230	1.40	4	35		61.3		0.3	F6: F; F8: A	Siehe Anleitung	82	2018
UFRX-450-3 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		3.231	1.260	230	1.64	33	48		62.0		0.3	F6: F; F8: A	Siehe Anleitung	85	2018
UFRX-450-4 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		4.212	3.773	230	2.14	236	81		62.6		0.2	F6: F; F8: A	Siehe Anleitung	87	2018
UFRX-450-5.5 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		4.522	5.302	230	2.29	385	94		64.3		0.2	F6: F; F8: A	Siehe Anleitung	90	2018
UFRX-450-7.5 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		4.800	7.084	230	2.44	573	106		66.6		0.2	F6: F; F8: A	Siehe Anleitung	92	2018
UFRX-450-10 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		5.008	9.374	230	2.54	822	115		67.4		0.2	F6: F; F8: A	Siehe Anleitung	94	2018
UFRX-500-2 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		5.283	3.239	230	2.68	51	30		63.3		0.2	F6: F; F8: A	Siehe Anleitung	83	2018
UFRX-500-3 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		5.650	4.048	230	2.87	74	35		64.0		0.2	F6: F; F8: A	Siehe Anleitung	86	2018
UFRX-500-4 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		5.471	3.587	230	2.78	60	33		64.7		0.2	F6: F; F8: A	Siehe Anleitung	88	2018
UFRX-500-5.5 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		5.838	4.398	230	2.96	85	37		66.3		0.2	F6: F; F8: A	Siehe Anleitung	90	2018
UFRX-500-7.5 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		6.549	6.348	230	3.32	150	47		68.6		0.1	F6: F; F8: A	Siehe Anleitung	92	2018
UFRX-500-10 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		7.221	8.866	230	3.66	247	57		69.7		0.1	F6: F; F8: A	Siehe Anleitung	95	2018
UFRX-500-15 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		7.855	11.956	230	3.99	378	67		69.7		0.1	F6: F; F8: A	Siehe Anleitung	98	2018
UFRX-500-20 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		8.142	13.956	230	4.13	467	72		69.2		0.1	F6: F; F8: A	Siehe Anleitung	99	2018
UFRX-560-3 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		4.906	2.093	230	1.68	41	48		63.6		0.2	F6: F; F8: A	Siehe Anleitung	72	2018
UFRX-560-4 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		5.352	2.859	230	1.83	76	57		64.3		0.2	F6: F; F8: A	Siehe Anleitung	75	2018
UFRX-560-5.5 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		6.147	4.938	230	2.11	188	75		66.0		0.2	F6: F; F8: A	Siehe Anleitung	77	2018
UFRX-560-7.5 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		6.826	7.694	230	2.34	363	93		68.4		0.2	F6: F; F8: A	Siehe Anleitung	79	2018
UFRX-560-10 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		7.119	9.347	230	2.44	476	101		69.2		0.2	F6: F; F8: A	Siehe Anleitung	81	2018
UFRX-560-15 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		7.600	13.329	230	2.60	764	115		69.2		0.2	F6: F; F8: A	Siehe Anleitung	84	2018
UFRX-560-20 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		7.914	18.435	230	2.71	1141	125		69.1		0.2	F6: F; F8: A	Siehe Anleitung	87	2018
UFRX-560-25 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		8.104	20.840	230	2.78	1335	131		69.7		0.1	F6: F; F8: A	Siehe Anleitung	89	2018
UFRX-560-30 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		8.073	21.035	230	2.77	1344	130		69.7		0.1	F6: F; F8: A	Siehe Anleitung	89	2018
UFRX-630-3 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		6.842	2.539	230	2.34	17	28		60.7		0.2	F6: F; F8: A	Siehe Anleitung	74	2018
UFRX-630-4 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		8.351	4.995	230	2.86	66	41		61.3		0.1	F6: F; F8: A	Siehe Anleitung	77	2018
UFRX-630-5.5 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		9.061	6.631	230	3.10	106	49		62.8		0.1	F6: F; F8: A	Siehe Anleitung	79	2018
UFRX-630-7.5 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		9.749	8.486	230	3.34	157	56		65.0		0.1	F6: F; F8: A	Siehe Anleitung	81	2018
UFRX-630-10 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		10.394	10.753	230	3.56	224	64		66.1		0.1	F6: F; F8: A	Siehe Anleitung	84	2018
UFRX-630-15 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		11.557	16.550	230	3.96	414	79		66.1		0.1	F6: F; F8: A	Siehe Anleitung	86	2018
UFRX-630-20 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		12.043	20.404	230	4.13	547	86		66.0		0.1	F6: F; F8: A	Siehe Anleitung	89	2018
UFRX-630-25 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		12.089	19.957	230	4.14	535	87		67.1		0.1	F6: F; F8: A	Siehe Anleitung	90	2018
UFRX-630-30 F6+F8 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		12.067	20.178	230	4.13	541	86		66.6		0.1	F6: F; F8: A	Siehe Anleitung	92	2018
UFRX-315-0.5 F7+F9	NRVU / UVU	Variable Drehzahl	Kein/e		1.412	0.743	230	2.15	64	50		47.9		0.3	F7: A; F9: A	Siehe Anleitung	74	2018
UFRX-315-0.75 F7+F9	NRVU / UVU	Variable Drehzahl	Kein/e		1.502	0.964	230	2.29	101	56		53.2		0.3	F7: A; F9: A	Siehe Anleitung	72	2018
UFRX-315-1 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		1.646	0.968	230	2.51	105	68		59.3		0.2	F7: A; F9: A	Siehe Anleitung	74	2018
UFRX-315-1.5 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		1.735	1.193	230	2.65	149	75		61.2		0.2	F7: A; F9: A	Siehe Anleitung	77	2018
UFRX-315-2 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		1.810	1.483	230	2.76	209	82		62.5		0.2	F7: A; F9: A	Siehe Anleitung	79	2018
UFRX-315-3 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		1.887	1.770	230	2.88	273	89		63.1		0.2	F7: A; F9: A	Siehe Anleitung	82	2018
UFRX-355-0.75 F7+F9	NRVU / UVU	Variable Drehzahl	Kein/e		1.831	0.806	230	1.49	34	38		50.8		0.4	F7: A; F9: A	Siehe Anleitung	71	2018
UFRX-355-1 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		1.979	0.784	230	1.61	32	44		59.0		0.3	F7: A; F9: A	Siehe Anleitung	73	2018
UFRX-355-1.5 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		2.193	1.133	230	1.78	67	54		60.8		0.3	F7: A; F9: A	Siehe Anleitung	76	2018
UFRX-355-2 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		2.393	1.569	230	1.95	119	64		62.2		0.3	F7: A; F9: A	Siehe Anleitung	78	2018
UFRX-355-3 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		2.568	2.150	230	2.09	195	74		62.8		0.3	F7: A; F9: A	Siehe Anleitung	80	2018
UFRX-355-4 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		2.795	3.267	230	2.27	357	88		63.3		0.2	F7: A; F9: A	Siehe Anleitung	83	2018
UFRX-355-5.5 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		3.007	4.541	230	2.45	564	101		65.0		0.2	F7: A; F9: A	Siehe Anleitung	85	2018
UFRX-400-1.5 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		2.376	0.653	230	1.93	3	13		60.4		0.3	F7: A; F9: A	Siehe Anleitung	78	2018
UFRX-400-2 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		2.566	0.815	230	2.09	6	16		61.7		0.3	F7: A; F9: A	Siehe Anleitung	80	2018
UFRX-400-3 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		2.938	1.263	230	2.39	18	21		62.5		0.2	F7: A; F9: A	Siehe Anleitung	83	2018
UFRX-400-4 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		4.073	3.853	230	3.31	123	40		63.0		0.2	F7: A; F9: A	Siehe Anleitung	85	2018
UFRX-400-5.5 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		4.406	4.909	230	3.58	178	46		64.7		0.1	F7: A; F9: A	Siehe Anleitung	88	2018
UFRX-400-7.5 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		4.715	6.344	230	3.83	258	53		67.0		0.1	F7: A; F9: A	Siehe Anleitung	90	2018
UFRX-450-2 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		2.743	0.714	230	1.39	5	38		61.3		0.3	F7: A; F9: A	Siehe Anleitung	82	2018
UFRX-450-3 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		3.202	1.271	230	1.62	38	52		62.0		0.3	F7: A; F9: A	Siehe Anleitung	85	2018
UFRX-450-4 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e		4.134	3.808	230	2.10	261	87		62.6		0.2	F7: A; F9: A	Siehe Anleitung	87	2018

ECODESIGN INFORMATION

Applies to non-residential ventilation units (NRVU)

According to Regulation EU No 1253/2014 of the European Commission, implementing Directive 2009/125/CE of European Parliament

SODECA, S.L.U.

www.sodeca.com

			%	m³/s	kW	W/m³/s	m/s	Pa	Pa	Pa	%	%	%			dBA	
UFRX-450-5.5 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	4.421	5.341	230	2.24	423	99		64.3	0.2	F7: A; F9: A	Siehe Anleitung	90	2018	
UFRX-450-7.5 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	4.674	7.118	230	2.37	625	111		66.6	0.2	F7: A; F9: A	Siehe Anleitung	92	2018	
UFRX-450-10 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	4.857	9.387	230	2.46	889	120		67.4	0.2	F7: A; F9: A	Siehe Anleitung	94	2018	
UFRX-500-2 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	4.473	3.279	230	2.27	223	102		63.3	0.2	F7: A; F9: A	Siehe Anleitung	83	2018	
UFRX-500-3 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	4.652	4.096	230	2.36	311	110		64.0	0.2	F7: A; F9: A	Siehe Anleitung	86	2018	
UFRX-500-4 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	4.578	3.631	230	2.32	261	107		64.7	0.2	F7: A; F9: A	Siehe Anleitung	88	2018	
UFRX-500-5.5 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	4.759	4.448	230	2.41	353	115		66.3	0.2	F7: A; F9: A	Siehe Anleitung	90	2018	
UFRX-500-7.5 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	5.048	6.391	230	2.56	584	130		68.6	0.2	F7: A; F9: A	Siehe Anleitung	92	2018	
UFRX-500-10 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	5.227	8.839	230	2.65	883	139		69.7	0.2	F7: A; F9: A	Siehe Anleitung	95	2018	
UFRX-500-15 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	5.330	11.738	230	2.70	1240	145		69.7	0.2	F7: A; F9: A	Siehe Anleitung	98	2018	
UFRX-500-20 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	5.317	13.546	230	2.70	1450	144		69.2	0.2	F7: A; F9: A	Siehe Anleitung	99	2018	
UFRX-560-3 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	4.862	2.101	230	1.67	46	52		63.6	0.2	F7: A; F9: A	Siehe Anleitung	72	2018	
UFRX-560-4 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	5.293	2.869	230	1.81	84	62		64.3	0.2	F7: A; F9: A	Siehe Anleitung	75	2018	
UFRX-560-5.5 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	6.048	4.948	230	2.07	207	81		66.0	0.2	F7: A; F9: A	Siehe Anleitung	77	2018	
UFRX-560-7.5 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	6.680	7.686	230	2.29	395	99		68.4	0.2	F7: A; F9: A	Siehe Anleitung	79	2018	
UFRX-560-10 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	6.949	9.319	230	2.38	516	107		69.2	0.2	F7: A; F9: A	Siehe Anleitung	81	2018	
UFRX-560-15 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	7.377	13.229	230	2.53	819	120		69.2	0.2	F7: A; F9: A	Siehe Anleitung	84	2018	
UFRX-560-20 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	7.639	18.203	230	2.62	1209	129		69.1	0.2	F7: A; F9: A	Siehe Anleitung	87	2018	
UFRX-560-25 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	7.807	20.541	230	2.67	1408	135		69.7	0.2	F7: A; F9: A	Siehe Anleitung	89	2018	
UFRX-560-30 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	7.775	20.728	230	2.66	1417	134		69.7	0.2	F7: A; F9: A	Siehe Anleitung	89	2018	
UFRX-630-3 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	6.035	2.696	230	2.07	76	81		60.7	0.2	F7: A; F9: A	Siehe Anleitung	74	2018	
UFRX-630-4 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	6.865	5.216	230	2.35	240	104		61.3	0.2	F7: A; F9: A	Siehe Anleitung	77	2018	
UFRX-630-5.5 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	7.181	6.807	230	2.46	356	114		62.8	0.2	F7: A; F9: A	Siehe Anleitung	79	2018	
UFRX-630-7.5 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	7.466	8.536	230	2.56	490	123		65.0	0.2	F7: A; F9: A	Siehe Anleitung	81	2018	
UFRX-630-10 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	7.677	10.552	230	2.63	649	130		66.1	0.2	F7: A; F9: A	Siehe Anleitung	84	2018	
UFRX-630-15 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	7.943	15.330	230	2.72	1032	140		66.1	0.2	F7: A; F9: A	Siehe Anleitung	86	2018	
UFRX-630-20 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	7.967	18.274	230	2.73	1261	141		66.0	0.2	F7: A; F9: A	Siehe Anleitung	89	2018	
UFRX-630-25 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	8.045	17.968	230	2.76	1248	143		67.1	0.1	F7: A; F9: A	Siehe Anleitung	90	2018	
UFRX-630-30 F7+F9 IE3	NRVU / UVU	Variable Drehzahl	Kein/e	8.006	18.120	230	2.74	1254	142		66.6	0.2	F7: A; F9: A	Siehe Anleitung	92	2018	