ECODESIGN INFORMATION

Applies to non-residential ventilation units (NRVU)

According to Regulation EU No 1253/2014 of the European Commission, implementing Directive 2009/125/CE of European Parliament

SODECA, S.L.U.

www.sodeca.com

c) Typology
d) Type of drive
e) Type of HRS
g) Nominal flowrate
h) Effective electric power input
i) SFPint
k) Nominal external pressure
l) Internal pressure drop of ventilation components
m) Internal pressure drop of non-ventilation components
327/2011
o1) Max. Internal leakage index
o2) Max. External leakage index
p) Energy performance of the filters
r) LWA radiated

b)	c)	d)	e)	f)	g)	h)	i)	j)	k)	l)	m)	n)	o1)	o2)	p)	q)	r)	ERP
				%	m^3/s	kW	$W/m^3/s$	m/s	Pa	Pa	Pa	%	%	%			dBA	
UFR-1240-4T G4+F6 IE3	NRVU / UVU	Muuttuva nopeus	Ei yhtään		0.688	0.553	230	1.68	193	78		51.4		0.4	G4: G; F6: F	Katso käyttöohjekirja	76	2018
UFR-1850-4T G4+F6 IE3	NRVU / UVU	Muuttuva nopeus	Ei yhtään		0.693	1.295	230	1.69	561	79		57.3		0.4	G4: G; F6: F	Katso käyttöohjekirja	86	2018
UFR-2056-4T G4+F6 IE3	NRVU / UVU	Muuttuva nopeus	Ei yhtään		1.726	2.083	230	2.96	359	85		57.8		0.2	G4: G; F6: F	Katso käyttöohjekirja	88	2018
UFR-2056-6T G4+F6 IE3	NRVU / UVU	Muuttuva nopeus	Ei yhtään		1.493	0.655	230	2.56	57	63		52.8		0.3	G4: G; F6: F	Katso käyttöohjekirja	78	2018
UFR-2263-4T G4+F6 IE3	NRVU / UVU	Muuttuva nopeus	Ei yhtään		1.144	3.629	230	1.63	770	60		60.9		0.4	G4: G; F6: F	Katso käyttöohjekirja	92	2018
UFR-2263-6T G4+F6 IE3	NRVU / UVU	Muuttuva nopeus	Ei yhtään		1.469	1.360	230	2.52	276	91		59.0		0.3	G4: G; F6: F	Katso käyttöohjekirja	82	2018
UFR-2071-4T G4+F6 IE3	NRVU / UVU	Muuttuva nopeus	Ei yhtään		1.045	4.877	230	1.29	1018	53		64.0		0.5	G4: G; F6: F	Katso käyttöohjekirja	101	2018
UFR-2071-6T-3 G4+F6 IE3	NRVU / UVU	Muuttuva nopeus	Ei yhtään		1.202	2.387	230	1.71	507	66		59.4		0.4	G4: G; F6: F	Katso käyttöohjekirja	86	2018
UFR-2071-6T-5.5 G4+F6 IE3	NRVU / UVU	Muuttuva nopeus	Ei yhtään		1.056	2.121	230	1.30	417	54		59.2		0.5	G4: G; F6: F	Katso käyttöohjekirja	88	2018
UFR-2880-6T G4+F6 IE3	NRVU / UVU	Muuttuva nopeus	Ei yhtään		1.181	2.937	230	1.46	662	67		59.7		0.4	G4: G; F6: F	Katso käyttöohjekirja	89	2018
UFR-1240-4T F6+F8 IE3	NRVU / UVU	Muuttuva nopeus	Ei yhtään		0.763	0.569	230	1.86	168	75		51.4		0.4	F6: F; F8: A	Katso käyttöohjekirja	76	2018
UFR-1850-4T F6+F8 IE3	NRVU / UVU	Muuttuva nopeus	Ei yhtään		0.807	1.347	230	1.97	523	84		57.3		0.4	F6: F; F8: A	Katso käyttöohjekirja	86	2018
UFR-2056-4T F6+F8 IE3	NRVU / UVU	Muuttuva nopeus	Ei yhtään		1.962	2.084	230	3.37	267	74		57.8		0.2	F6: F; F8: A	Katso käyttöohjekirja	88	2018
UFR-2056-6T F6+F8 IE3	NRVU / UVU	Muuttuva nopeus	Ei yhtään		1.595	0.638	230	2.74	36	49		52.8		0.2	F6: F; F8: A	Katso käyttöohjekirja	78	2018
UFR-2263-4T F6+F8 IE3	NRVU / UVU	Muuttuva nopeus	Ei yhtään		1.318	3.860	230	1.88	750	64		60.9		0.3	F6: F; F8: A	Katso käyttöohjekirja	92	2018
UFR-2263-6T F6+F8 IE3	NRVU / UVU	Muuttuva nopeus	Ei yhtään		1.636	1.361	230	2.81	232	88		59.0		0.2	F6: F; F8: A	Katso käyttöohjekirja	82	2018
UFR-2071-4T F6+F8 IE3	NRVU / UVU	Muuttuva nopeus	Ei yhtään		1.206	5.174	230	1.49	1006	57		64.0		0.4	F6: F; F8: A	Katso käyttöohjekirja	101	2018
UFR-2071-6T-3 F6+F8 IE3	NRVU / UVU	Muuttuva nopeus	Ei yhtään		1.402	2.447	230	2.00	477	72		59.4		0.3	F6: F; F8: A	Katso käyttöohjekirja	86	2018
UFR-2071-6T-5.5 F6+F8 IE3	NRVU / UVU	Muuttuva nopeus	Ei yhtään		1.212	2.243	230	1.50	405	58		59.2		0.4	F6: F; F8: A	Katso käyttöohjekirja	88	2018
UFR-2880-6T F6+F8 IE3	NRVU / UVU	Muuttuva nopeus	Ei yhtään		1.366	3.068	230	1.69	641	73		59.7		0.4	F6: F; F8: A	Katso käyttöohjekirja	89	2018
UFR-1240-4T F7+F9 IE3	NRVU / UVU	Muuttuva nopeus	Ei yhtään		0.724	0.561	230	1.77	181	76		51.4		0.4	F7: A; F9: A	Katso käyttöohjekirja	76	2018
UFR-1850-4T F7+F9 IE3	NRVU / UVU	Muuttuva nopeus	Ei yhtään		0.746	1.320	230	1.82	544	81		57.3		0.4	F7: A; F9: A	Katso käyttöohjekirja	86	2018
UFR-2056-4T F7+F9 IE3	NRVU / UVU	Muuttuva nopeus	Ei yhtään		1.839	2.088	230	3.16	316	80		57.8		0.2	F7: A; F9: A	Katso käyttöohjekirja	88	2018
UFR-2056-6T F7+F9 IE3	NRVU / UVU	Muuttuva nopeus	Ei yhtään		1.544	0.647	230	2.65	46	57		52.8		0.3	F7: A; F9: A	Katso käyttöohjekirja	78	2018
UFR-2263-4T F7+F9 IE3	NRVU / UVU	Muuttuva nopeus	Ei yhtään		1.225	3.737	230	1.74	761	62		60.9		0.4	F7: A; F9: A	Katso käyttöohjekirja	92	2018
UFR-2263-6T F7+F9 IE3	NRVU / UVU	Muuttuva nopeus	Ei yhtään		1.550	1.363	230	2.66	255	90		59.0		0.3	F7: A; F9: A	Katso käyttöohjekirja	82	2018
UFR-2071-4T F7+F9 IE3	NRVU / UVU	Muuttuva nopeus	Ei yhtään		1.120	5.015	230	1.38	1012	55		64.0		0.4	F7: A; F9: A	Katso käyttöohjekirja	101	2018
UFR-2071-6T-3 F7+F9 IE3	NRVU / UVU	Muuttuva nopeus	Ei yhtään		1.295	2.417	230	1.84	493	69		59.4		0.3	F7: A; F9: A	Katso käyttöohjekirja	86	2018
UFR-2071-6T-5.5 F7+F9 IE3	NRVU / UVU	Muuttuva nopeus	Ei yhtään		1.129	2.178	230	1.39	411	56		59.2		0.4	F7: A; F9: A	Katso käyttöohjekirja	88	2018
UFR-2880-6T F7+F9 IE3	NRVU / UVU	Muuttuva nopeus	Ei yhtään		1.268	3.000	230	1.57	652	70		59.7		0.4	F7: A; F9: A	Katso käyttöohjekirja	89	2018