

ECODESIGN INFORMATION

Applies to non-residential ventilation units (NRVU)

According to Regulation EU No 1253/2014 of the European Commission, implementing Directive 2009/125/CE of European Parliament

SODECA, S.L.U.

www.sodeca.com

c) Typology
d) Type of drive
e) Type of HRS

g) Nominal flowrate
h) Effective electric power input
i) SFPint

k) Nominal external pressure
l) Internal pressure drop of ventilation components
m) Internal pressure drop of non-ventilation components

327/2011
o1) Max. Internal leakage index
o2) Max. External leakage index
p) Energy performance of the filters

r) LWA radiated

b)	c)	d)	e)	f)	g)	h)	i)	j)	k)	l)	m)	n)	o1)	o2)	p)	q)	r)	ERP
				%	m ³ /s	kW	W/m ³ /s	m/s	Pa	Pa	Pa	%	%	%			dBA	
UFR-1240-4T G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		0.688	0.553	230	1.68	193	78		51.4		0.4	G4: G; F6: F	Veure manual	76	2018
UFR-1850-4T G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		0.693	1.295	230	1.69	561	79		57.3		0.4	G4: G; F6: F	Veure manual	86	2018
UFR-2056-4T G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		1.726	2.083	230	2.96	359	85		57.8		0.2	G4: G; F6: F	Veure manual	88	2018
UFR-2056-6T G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		1.493	0.655	230	2.56	57	63		52.8		0.3	G4: G; F6: F	Veure manual	78	2018
UFR-2263-4T G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		1.144	3.629	230	1.63	770	60		60.9		0.4	G4: G; F6: F	Veure manual	92	2018
UFR-2263-6T G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		1.469	1.360	230	2.52	276	91		59.0		0.3	G4: G; F6: F	Veure manual	82	2018
UFR-2071-4T G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		1.045	4.877	230	1.29	1018	53		64.0		0.5	G4: G; F6: F	Veure manual	101	2018
UFR-2071-6T-3 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		1.202	2.387	230	1.71	507	66		59.4		0.4	G4: G; F6: F	Veure manual	86	2018
UFR-2071-6T-5.5 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		1.056	2.121	230	1.30	417	54		59.2		0.5	G4: G; F6: F	Veure manual	88	2018
UFR-2880-6T G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		1.181	2.937	230	1.46	662	67		59.7		0.4	G4: G; F6: F	Veure manual	89	2018
UFR-1240-4T F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		0.763	0.569	230	1.86	168	75		51.4		0.4	F6: F; F8: A	Veure manual	76	2018
UFR-1850-4T F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		0.807	1.347	230	1.97	523	84		57.3		0.4	F6: F; F8: A	Veure manual	86	2018
UFR-2056-4T F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		1.962	2.084	230	3.37	267	74		57.8		0.2	F6: F; F8: A	Veure manual	88	2018
UFR-2056-6T F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		1.595	0.638	230	2.74	36	49		52.8		0.2	F6: F; F8: A	Veure manual	78	2018
UFR-2263-4T F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		1.318	3.860	230	1.88	750	64		60.9		0.3	F6: F; F8: A	Veure manual	92	2018
UFR-2263-6T F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		1.636	1.361	230	2.81	232	88		59.0		0.2	F6: F; F8: A	Veure manual	82	2018
UFR-2071-4T F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		1.206	5.174	230	1.49	1006	57		64.0		0.4	F6: F; F8: A	Veure manual	101	2018
UFR-2071-6T-3 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		1.402	2.447	230	2.00	477	72		59.4		0.3	F6: F; F8: A	Veure manual	86	2018
UFR-2071-6T-5.5 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		1.212	2.243	230	1.50	405	58		59.2		0.4	F6: F; F8: A	Veure manual	88	2018
UFR-2880-6T F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		1.366	3.068	230	1.69	641	73		59.7		0.4	F6: F; F8: A	Veure manual	89	2018
UFR-1240-4T F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap		0.724	0.561	230	1.77	181	76		51.4		0.4	F7: A; F9: A	Veure manual	76	2018
UFR-1850-4T F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap		0.746	1.320	230	1.82	544	81		57.3		0.4	F7: A; F9: A	Veure manual	86	2018
UFR-2056-4T F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap		1.839	2.088	230	3.16	316	80		57.8		0.2	F7: A; F9: A	Veure manual	88	2018
UFR-2056-6T F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap		1.544	0.647	230	2.65	46	57		52.8		0.3	F7: A; F9: A	Veure manual	78	2018
UFR-2263-4T F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap		1.225	3.737	230	1.74	761	62		60.9		0.4	F7: A; F9: A	Veure manual	92	2018
UFR-2263-6T F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap		1.550	1.363	230	2.66	255	90		59.0		0.3	F7: A; F9: A	Veure manual	82	2018
UFR-2071-4T F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap		1.120	5.015	230	1.38	1012	55		64.0		0.4	F7: A; F9: A	Veure manual	101	2018
UFR-2071-6T-3 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap		1.295	2.417	230	1.84	493	69		59.4		0.3	F7: A; F9: A	Veure manual	86	2018
UFR-2071-6T-5.5 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap		1.129	2.178	230	1.39	411	56		59.2		0.4	F7: A; F9: A	Veure manual	88	2018
UFR-2880-6T F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap		1.268	3.000	230	1.57	652	70		59.7		0.4	F7: A; F9: A	Veure manual	89	2018