

ECODESIGN INFORMATION

According to Regulation EU No 327/2011 of the European Commission, implementing Directive 2009/125/CE of European Parliament
Apply to fans

SODECA, S.L.U.

www.sodeca.com

ERP: Performance at the best efficiency point (BEP).

| | |
|------------|----------------------|
| MC | Measurement category |
| EC | Efficiency category |
| VSD | Variable Speed Drive |
| SR | Specific ratio |

| | |
|--------------------------|--|
| [m³/h] | Flowrate |
| [Pa] | Static pressure or total (depending on EC) |
| [RPM] | Rotation per minute |

| | |
|---------------|------------------|
| ηe [%] | Efficiency |
| N | Efficiency grade |
| [kW] | Input power |

| Model | MC | EC | VSD | SR | ηe[%] | N | [kW] | [m ³ /h] | [Pa] | [RPM] |
|---------------------------------|----|----|-----|----|--------------------|---|------|---------------------|------|-------|
| HTMV/ATEX-40-4T-0.75/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-40-6T-0.75/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-45-4T-0.75/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-45-6T-0.75/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-50-4T-1/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-50-6T-0.75/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-56-4T-1/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-56-4T-1.5/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-56-4T-2/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-56-6T-0.75/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-63-4T-1.5/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-63-4T-2/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-63-4T-3/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-63-4T-4/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-63-6T-0.75/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-63-6T-1/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-71-4T-2/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-71-4T-3/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-71-4T-4/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-71-6T-0.75/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-71-6T-1/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-71-6T-1.5/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-80-4T-4/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-80-4T-5.5/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-80-6T-1.5/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-80-6T-2/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-80-6T-3/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-90-4T-5.5/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-90-4T-7.5/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-90-4T-10/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-90-6T-2/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-90-6T-3/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-90-6T-4/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-100-4T-7.5/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-100-4T-10/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-100-4T-15/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-100-4T-20/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-100-6T-3/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-100-6T-4/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-100-6T-5.5/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-125-4T/6-25/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-125-4T/6-30/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-125-4T/6-40/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-125-4T/6-50/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-125-4T/9-25/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-125-4T/9-30/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-125-4T/9-40/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-125-4T/9-50/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-125-6T/6-5.5/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-125-6T/6-7.5/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-125-6T/6-10/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-125-6T/6-15/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-125-6T/6-20/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-125-6T/9-10/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-125-6T/9-15/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-125-6T/9-20/2G Ex eb | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-40-4T-0.75/2G Ex db | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-40-6T-0.75/2G Ex db | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-45-4T-0.75/2G Ex db | | | | | ErP: Exclude. ATEX | | | | | |
| HTMV/ATEX-45-6T-0.75/2G Ex db | | | | | ErP: Exclude. ATEX | | | | | |

| Model | MC | EC | VSD | SR | η_e [%] | N | [kW] | [m ³ /h] | [Pa] | [RPM] |
|---------------------------------|----|----|-----|----|--------------|---|------|---------------------|------|--------------------|
| HTMV/ATEX-50-4T-1/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-50-6T-0.75/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-56-4T-1/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-56-4T-1.5/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-56-4T-2/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-56-6T-0.75/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-63-4T-1.5/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-63-4T-2/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-63-4T-3/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-63-4T-4/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-63-6T-0.75/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-63-6T-1/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-71-4T-2/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-71-4T-3/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-71-4T-4/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-71-6T-0.75/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-71-6T-1/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-71-6T-1.5/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-80-4T-4/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-80-4T-5.5/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-80-6T-1.5/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-80-6T-2/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-80-6T-3/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-90-4T-5.5/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-90-4T-7.5/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-90-4T-10/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-90-6T-2/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-90-6T-3/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-90-6T-4/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-100-4T-7.5/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-100-4T-10/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-100-4T-15/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-100-4T-20/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-100-6T-3/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-100-6T-4/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-100-6T-5.5/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-125-4T/6-25/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-125-4T/6-30/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-125-4T/6-40/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-125-4T/6-50/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-125-4T/9-25/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-125-4T/9-30/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-125-4T/9-40/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-125-4T/9-50/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-125-6T/6-5.5/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-125-6T/6-7.5/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-125-6T/6-10/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-125-6T/6-15/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-125-6T/6-20/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-125-6T/9-10/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-125-6T/9-15/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |
| HTMV/ATEX-125-6T/9-20/2G Ex db | | | | | | | | | | ErP: Exclude. ATEX |