

## INFORMATION OM EKODESIGN

Enligt Europeiska kommissionens förordning nr 327/2011 som tillämpar Europaparlamentets direktiv 2009/125/EG  
Tillämpas på fläktar

SODECA, S.L.U.

www.sodeca.com

### ERP: Prestanda vid bästa effektivitetspunkt (BEP)

|     |                       |
|-----|-----------------------|
| MC  | Måtningskategori      |
| EC  | Effektivitetskategori |
| VSD | Variabel hastighet    |
| SR  | Specifik förhållande  |

|                     |                             |
|---------------------|-----------------------------|
| [m <sup>3</sup> /h] | Flödeshastighet             |
| [Pa]                | Statiskt tryck/totalt tryck |
| [RPM]               | Hastighet                   |

|                    |                   |
|--------------------|-------------------|
| η <sub>e</sub> [%] | Effektivitet      |
| N                  | Effektivitetsgrad |
| [kW]               | Ineffekt          |

| Modell                         | MC | EC | VSD | SR | η <sub>e</sub> [%] | N | [kW] | [m <sup>3</sup> /h] | [Pa] | [RPM]              |
|--------------------------------|----|----|-----|----|--------------------|---|------|---------------------|------|--------------------|
| PF/ATEX-H925-2T-0.5/2G Ex eb   |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H925-2T-0.75/2G Ex eb  |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H925-2T-1/2G Ex eb     |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H925-2T-1.5/2G Ex eb   |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H925-2T-2/2G Ex eb     |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1028-2T-0.75/2G Ex eb |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1028-2T-1/2G Ex eb    |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1028-2T-1.5/2G Ex eb  |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1028-2T-2/2G Ex eb    |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1028-4T-0.5/2G Ex eb  |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1031-2T-1.5/2G Ex eb  |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1031-2T-2/2G Ex eb    |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1031-4T-0.5/2G Ex eb  |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1031-4T-0.75/2G Ex eb |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1031-4T-1/2G Ex eb    |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1031-4T-1.5/2G Ex eb  |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1135-2T-3/2G Ex eb    |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1135-4T-0.75/2G Ex eb |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1135-4T-1/2G Ex eb    |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1135-4T-1.5/2G Ex eb  |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1135-4T-2/2G Ex eb    |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1240-4T-1/2G Ex eb    |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1240-4T-1.5/2G Ex eb  |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1240-4T-2/2G Ex eb    |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1240-4T-3/2G Ex eb    |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1240-4T-4/2G Ex eb    |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1445-4T-2/2G Ex eb    |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1445-4T-3/2G Ex eb    |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1445-4T-4/2G Ex eb    |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1445-4T-5.5/2G Ex eb  |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1445-4T-7.5/2G Ex eb  |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1650-4T-2/2G Ex eb    |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1650-4T-3/2G Ex eb    |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1650-4T-4/2G Ex eb    |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1650-4T-5.5/2G Ex eb  |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1650-4T-7.5/2G Ex eb  |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1650-4T-10/2G Ex eb   |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1856-4T-3/2G Ex eb    |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1856-4T-4/2G Ex eb    |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1856-4T-5.5/2G Ex eb  |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1856-4T-7.5/2G Ex eb  |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1856-4T-10/2G Ex eb   |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1856-4T-15/2G Ex eb   |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1856-6T-2/2G Ex eb    |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1663-4T-5.5/2G Ex eb  |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1663-4T-7.5/2G Ex eb  |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1663-4T-10/2G Ex eb   |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1663-4T-15/2G Ex eb   |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1663-6T-3/2G Ex eb    |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1663-6T-4/2G Ex eb    |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1871-4T-7.5/2G Ex eb  |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1871-4T-10/2G Ex eb   |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1871-4T-15/2G Ex eb   |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1871-4T-20/2G Ex eb   |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1871-6T-4/2G Ex eb    |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H1871-6T-5.5/2G Ex eb  |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H2180-4T-20/2G Ex eb   |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H2180-4T-25/2G Ex eb   |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H2180-6T-5.5/2G Ex eb  |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-H2180-6T-7.5/2G Ex eb  |    |    |     |    |                    |   |      |                     |      | ErP: Uteslut. ATEX |

| Modell                          | MC | EC | VSD | SR | ηe[%] | N | [kW] | [m³/h] | [Pa] | [RPM]              |
|---------------------------------|----|----|-----|----|-------|---|------|--------|------|--------------------|
| PF/ATEX-H2180-6T-10/2G Ex eb    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H2180-6T-15/2G Ex eb    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-925-2T-0.5/2G Ex eb   |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-925-2T-0.75/2G Ex eb  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-925-2T-1/2G Ex eb     |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-925-2T-1.5/2G Ex eb   |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-925-2T-2/2G Ex eb     |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1028-2T-0.75/2G Ex eb |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1028-2T-1/2G Ex eb    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1028-2T-1.5/2G Ex eb  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1028-2T-2/2G Ex eb    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1028-4T-0.5/2G Ex eb  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1031-2T-1.5/2G Ex eb  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1031-2T-2/2G Ex eb    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1031-4T-0.5/2G Ex eb  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1031-4T-0.75/2G Ex eb |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1031-4T-1/2G Ex eb    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1135-2T-3/2G Ex eb    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1135-4T-0.75/2G Ex eb |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1135-4T-1/2G Ex eb    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1135-4T-1.5/2G Ex eb  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1135-4T-2/2G Ex eb    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1240-4T-1/2G Ex eb    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1240-4T-1.5/2G Ex eb  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1240-4T-2/2G Ex eb    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1240-4T-3/2G Ex eb    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1240-4T-4/2G Ex eb    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1445-4T-2/2G Ex eb    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1445-4T-3/2G Ex eb    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1445-4T-4/2G Ex eb    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1445-4T-5.5/2G Ex eb  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1445-4T-7.5/2G Ex eb  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1650-4T-2/2G Ex eb    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1650-4T-3/2G Ex eb    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1650-4T-4/2G Ex eb    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1650-4T-5.5/2G Ex eb  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1650-4T-7.5/2G Ex eb  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1650-4T-10/2G Ex eb   |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1856-4T-3/2G Ex eb    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1856-4T-4/2G Ex eb    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1856-4T-5.5/2G Ex eb  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1856-4T-7.5/2G Ex eb  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1856-4T-10/2G Ex eb   |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1856-4T-15/2G Ex eb   |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1856-6T-2/2G Ex eb    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1663-4T-5.5/2G Ex eb  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1663-4T-7.5/2G Ex eb  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1663-4T-10/2G Ex eb   |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1663-4T-15/2G Ex eb   |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1663-6T-3/2G Ex eb    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1663-6T-4/2G Ex eb    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-925-2T-0.5/2G Ex db   |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-925-2T-0.75/2G Ex db  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-925-2T-1/2G Ex db     |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-925-2T-1.5/2G Ex db   |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-925-2T-2/2G Ex db     |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1028-2T-0.75/2G Ex db |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1028-2T-1/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1028-2T-1.5/2G Ex db  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1028-2T-2/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1028-4T-0.5/2G Ex db  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1031-2T-1.5/2G Ex db  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1031-2T-2/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1031-4T-0.5/2G Ex db  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1031-4T-0.75/2G Ex db |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1031-4T-1/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1135-2T-3/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1135-4T-0.75/2G Ex db |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1135-4T-1/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1135-4T-1.5/2G Ex db  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1135-4T-2/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1240-4T-1/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1240-4T-1.5/2G Ex db  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1240-4T-2/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |

| Modell                          | MC | EC | VSD | SR | ηe[%] | N | [kW] | [m³/h] | [Pa] | [RPM]              |
|---------------------------------|----|----|-----|----|-------|---|------|--------|------|--------------------|
| PF/ATEX-H-1240-4T-3/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1240-4T-4/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1445-4T-2/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1445-4T-3/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1445-4T-4/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1445-4T-5.5/2G Ex db  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1445-4T-7.5/2G Ex db  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1650-4T-2/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1650-4T-3/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1650-4T-4/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1650-4T-5.5/2G Ex db  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1650-4T-7.5/2G Ex db  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1650-4T-10/2G Ex db   |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1856-4T-3/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1856-4T-4/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1856-4T-5.5/2G Ex db  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1856-4T-7.5/2G Ex db  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1856-4T-10/2G Ex db   |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1856-4T-15/2G Ex db   |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1856-6T-2/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1663-4T-5.5/2G Ex db  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1663-4T-7.5/2G Ex db  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1663-4T-10/2G Ex db   |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1663-4T-15/2G Ex db   |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1663-6T-3/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1663-6T-4/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1871-4T-7.5/2G Ex db  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1871-4T-10/2G Ex db   |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1871-4T-15/2G Ex db   |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1871-4T-20/2G Ex db   |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1871-6T-4/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-1871-6T-5.5/2G Ex db  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-2180-4T-20/2G Ex db   |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-2180-4T-25/2G Ex db   |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-2180-6T-5.5/2G Ex db  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-2180-6T-7.5/2G Ex db  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-2180-6T-10/2G Ex db   |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-H-2180-6T-15/2G Ex db   |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-925-2T-0.5/2G Ex db   |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-925-2T-0.75/2G Ex db  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-925-2T-1/2G Ex db     |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-925-2T-1.5/2G Ex db   |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-925-2T-2/2G Ex db     |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1028-2T-0.75/2G Ex db |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1028-2T-1/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1028-2T-1.5/2G Ex db  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1028-2T-2/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1028-4T-0.5/2G Ex db  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1031-2T-1.5/2G Ex db  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1031-2T-2/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1031-4T-0.5/2G Ex db  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1031-4T-0.75/2G Ex db |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1031-4T-1/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1135-2T-3/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1135-4T-0.75/2G Ex db |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1135-4T-1/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1135-4T-1.5/2G Ex db  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1135-4T-2/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1240-4T-1/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1240-4T-1.5/2G Ex db  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1240-4T-2/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1240-4T-3/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1240-4T-4/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1445-4T-2/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1445-4T-3/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1445-4T-4/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1445-4T-5.5/2G Ex db  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1445-4T-7.5/2G Ex db  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1650-4T-2/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1650-4T-3/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1650-4T-4/2G Ex db    |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1650-4T-5.5/2G Ex db  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1650-4T-7.5/2G Ex db  |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1650-4T-10/2G Ex db   |    |    |     |    |       |   |      |        |      | ErP: Uteslut. ATEX |

| Modell                         | MC | EC | VSD | SR | $\eta_e$ [%] | N | [kW] | [m <sup>3</sup> /h] | [Pa] | [RPM]              |
|--------------------------------|----|----|-----|----|--------------|---|------|---------------------|------|--------------------|
| PF/ATEX-V-1856-4T-3/2G Ex db   |    |    |     |    |              |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1856-4T-4/2G Ex db   |    |    |     |    |              |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1856-4T-5.5/2G Ex db |    |    |     |    |              |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1856-4T-7.5/2G Ex db |    |    |     |    |              |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1856-4T-10/2G Ex db  |    |    |     |    |              |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1856-4T-15/2G Ex db  |    |    |     |    |              |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1856-6T-2/2G Ex db   |    |    |     |    |              |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1663-4T-5.5/2G Ex db |    |    |     |    |              |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1663-4T-7.5/2G Ex db |    |    |     |    |              |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1663-4T-10/2G Ex db  |    |    |     |    |              |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1663-4T-15/2G Ex db  |    |    |     |    |              |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1663-6T-3/2G Ex db   |    |    |     |    |              |   |      |                     |      | ErP: Uteslut. ATEX |
| PF/ATEX-V-1663-6T-4/2G Ex db   |    |    |     |    |              |   |      |                     |      | ErP: Uteslut. ATEX |