


## Mounting arrangements

### SYSTEM

# 1

#### SYSTEM 1

Transmission drive, impeller mounted on the support shaft.  
Support mounted on the pedestal.




### SYSTEM

# 8

#### SYSTEM 8

Elastic coupling drive, impeller mounted on the support shaft, mounted on the motor via an elastic coupling. Everything mounted together on a fan pedestal.  
For dimensions please consult with our technical department.




### SYSTEM

# 4

#### SYSTEM 4

Direct drive, impeller mounted on the motor shaft, mounted on the pedestal.




### SYSTEM

# 9

#### SYSTEM 9

Transmission drive, identical to SYSTEM 1, with the motor mounted on the side of the pedestal, in position "W" or "Z".




### SYSTEM

# 5

#### SYSTEM 5

Direct drive, impeller mounted on the motor shaft, flange motor mounted on the fan casing.



### SYSTEM

# 12

#### SYSTEM 12

Transmission drive, identical to SYSTEM 1, with the motor and fan mounted on the common bench.  
Motor positions "W" or "Z" and exceptionally "X" or "Y".

