

INFORMATION OM EKODESIGN

Enligt Europeiska kommissionens förordning nr 327/2011 som tillämpar Europaparlamentets direktiv 2009/125/EG
Tillämpas på fläktar

SODECA, S.L.U.

www.sodeca.com

ERP: Prestanda vid bästa effektivitetspunkt (BEP)

| | |
|-----|-----------------------|
| MC | Måtningskategori |
| EC | Effektivitetskategori |
| VSD | Variabel hastighet |
| SR | Specifik förhållande |

| | |
|---------------------|-----------------------------|
| [m ³ /h] | Flödeshastighet |
| [Pa] | Statiskt tryck/totalt tryck |
| [RPM] | Hastighet |

| | |
|--------------------|-------------------|
| η _e [%] | Effektivitet |
| N | Effektivitetsgrad |
| [kW] | Ineffekt |

| Modell | MC | EC | VSD | SR | η _e [%] | N | [kW] | [m ³ /h] | [Pa] | [RPM] |
|---------------------------------|----|----|-----|----|--------------------|---|------|---------------------|------|--------------------|
| HTMV/ATEX-40-4T-0.75/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-40-6T-0.75/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-45-4T-0.75/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-45-6T-0.75/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-50-4T-1/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-50-6T-0.75/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-56-4T-1/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-56-4T-1.5/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-56-4T-2/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-56-6T-0.75/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-63-4T-1.5/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-63-4T-2/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-63-4T-3/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-63-4T-4/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-63-6T-0.75/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-63-6T-1/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-71-4T-2/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-71-4T-3/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-71-4T-4/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-71-6T-0.75/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-71-6T-1/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-71-6T-1.5/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-80-4T-4/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-80-4T-5.5/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-80-6T-1.5/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-80-6T-2/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-80-6T-3/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-90-4T-5.5/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-90-4T-7.5/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-90-4T-10/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-90-6T-2/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-90-6T-3/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-90-6T-4/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-100-4T-7.5/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-100-4T-10/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-100-4T-15/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-100-4T-20/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-100-6T-3/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-100-6T-4/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-100-6T-5.5/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-4T/6-25/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-4T/6-30/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-4T/6-40/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-4T/6-50/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-4T/9-25/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-4T/9-30/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-4T/9-40/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-4T/9-50/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-6T/6-5.5/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-6T/6-7.5/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-6T/6-10/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-6T/6-15/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-6T/6-20/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-6T/9-10/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-6T/9-15/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-6T/9-20/2G Ex eb | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-40-4T-0.75/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-40-6T-0.75/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-45-4T-0.75/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |

| Modell | MC | EC | VSD | SR | η_e [%] | N | [kW] | [m³/h] | [Pa] | [RPM] |
|---------------------------------|----|----|-----|----|--------------|---|------|--------|------|--------------------|
| HTMV/ATEX-45-6T-0.75/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-50-4T-1/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-50-6T-0.75/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-56-4T-1/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-56-4T-1.5/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-56-4T-2/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-56-6T-0.75/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-63-4T-1.5/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-63-4T-2/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-63-4T-3/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-63-4T-4/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-63-6T-0.75/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-63-6T-1/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-71-4T-2/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-71-4T-3/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-71-4T-4/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-71-6T-0.75/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-71-6T-1/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-71-6T-1.5/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-80-4T-4/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-80-4T-5.5/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-80-6T-1.5/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-80-6T-2/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-80-6T-3/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-90-4T-5.5/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-90-4T-7.5/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-90-4T-10/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-90-6T-2/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-90-6T-3/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-90-6T-4/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-100-4T-7.5/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-100-4T-10/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-100-4T-15/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-100-4T-20/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-100-6T-3/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-100-6T-4/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-100-6T-5.5/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-4T/6-25/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-4T/6-30/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-4T/6-40/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-4T/6-50/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-4T/9-25/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-4T/9-30/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-4T/9-40/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-4T/9-50/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-6T/6-5.5/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-6T/6-7.5/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-6T/6-10/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-6T/6-15/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-6T/6-20/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-6T/9-10/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-6T/9-15/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |
| HTMV/ATEX-125-6T/9-20/2G Ex db | | | | | | | | | | ErP: Uteslut. ATEX |